YARP RPC ports

RPC stands for "Remote Procedure Call", and in YARP is used to refer to communication that consists of a message and a reply to that message.

The timing of processes is going to become tightly coupled, and a network of processes written this way is much less robust and malleable than with streaming communication.

RPC client expects to connect to a single server, and receive replies on the same connection.

RPC server expects to receive connections from multiple clients, and to reply to them via those connections.



YARP RpcServer

RpcServer is a port that expects to receive connections from multiple clients, and to reply to them via those connections.

RpcServer rpcServer;



YARP RPCServer::read()

```
bool RpcServer::read ( PortReader & reader,

bool willReply = true
)
```

Read an object from the port.

Parameters

reader any object that knows how to read itself from a network connection - see for example Bottle willReply you must set this to true if you intend to call reply()

Returns

true iff the object is successfully read

Reimplemented from yarp::os::AbstractContactable.



YARP RPCServer::reply()

reply()

bool yarp::os::AbstractContactable::reply (PortWriter & writer)

Send an object as a reply to an object read from the port.

Only call this method if you set the willReply flag to true when you called Port::read.

Parameters

writer any object that knows how to write itself to a network connection - see for example Bottle

Returns

true iff the object is successfully written

Implements yarp::os::UnbufferedContactable.

Reimplemented in yarp::os::RpcClient.



YARP RpcClient

RpcClient is a port that connects to a single server, and receives replies on the same connection.

RpcClient rpcClient;

The connect is -> yarp.connect(client, server)



YARP RpcClient::write()

Write an object to the port, then expect one back.

Parameters

writer any object that knows how to write itself to a network connection - see for example Bottle

reader any object that knows how to read itself from a network connection - see for example Bottle

Returns

true iff an object is successfully written and read

Port.write(fullbott,bott)

Implements yarp::os::UnbufferedContactable.

Reimplemented in yarp::os::RpcServer.



Excercise

Make a client that connects to the RPC port of the iCub_SIM (/icubSim/head/rpc:i) and send commands to all joints (from 0 to 5) to move the head from -30 to 30 degrees in 60 steps.

```
Bottle req;
req.addString("set");
req.addString("pos");
req.addInt8(3);
req.addDouble(value));
```

